



FM52, FM62,
FM82, FM65C
& FM8SUB
simple
set-up guide


thank you for choosing JBL. For over 50 years, JBL has been involved in every aspect of musical and film recording and reproduction, from live performances to monitoring the recordings you play in your home, car, or office.


We're confident that the **JBL loudspeakers** you have chosen will provide every note of enjoyment that you expected – and that when you think about purchasing additional audio equipment for your home, car, or office you will once again choose JBL.

Please take a moment to complete the enclosed profile card. It enables us to keep you posted on our latest advancements, and helps us to better understand our customers and build products that meet your needs and expectations.


One. Speaker Placement


FM52, FM62, FM82 as front speakers






FM52, FM62, FM82 as rear speakers






FM65C in ceiling



FM8SUB subwoofer in wall



two. Speaker Connections

Connection Tips


Wire Length

Up to 20 ft. Up to 30 ft. Greater than 30 ft.

Recommended Size


16 gauge 12 gauge 10 gauge

The wires for both speakers should be the same length. If one speaker is placed closer to the amplifier than the other, hide the excess wire behind the wall.



Speakers and electronics terminals have corresponding (+) and (-) terminals. It is important to connect both speakers identically: (+) on the speaker to (+) on the amplifier and (-) on the speaker to (-) on the amplifier. Wiring "out of phase" results in thin sound, weak bass and a poor stereo image.

FM52, FM62, FM82, FM65C




Front or Rear Speaker Outputs

FM8SUB

The FM8SUB has two speaker connections. Connect one set of terminals, along with your left


satellite to the left channel of your amplifier. Connect the other set of terminals, along with your right satellite to the right channel of your amplifier.



three. Installation


The FM Series flush-mount speakers were designed to be easily installed. However, if you are unsure of your ability to properly install these loudspeakers, please contact your dealer or a qualified installer.

Tools Needed




Carpenter's level

FM52, FM62, FM82 Installation Kit






Pencil




Speaker frame




Thread-forming screws

Awl




Retainer clips




Mounting brackets


Existing Construction




Step One: Remove the grille from the speaker frame.




Step Two:Determine the correct speaker location.




Step Three:Determine the speaker-frame location.




Step Four: Cut the dry wall.




Step Five:
Place the mounting bracket on
the speaker frame using the
mounting guides (marked 3/8",
1/2", 5/8", and 3/4") corresponding to the thickness of
the dry wall.



Step Six: Place the frame assembly in the wall.




Step Seven:
Connect the speaker wires to
the baffle assembly and install
baffle assembly in frame.
Do not overtighten the baffle
screws.




Step Eight: Replace the metal grille.


New Construction




Step One: Remove the grille from the speaker frame.



Step Two: Attach the proper mounting bracket, marked and preset at 3/8", 1/2", 5/8", and 3/4" to the speaker frame.




Step Three: Determine the correct speaker location.




Step Four:
Nail or screw the speaker frame assembly to the wall studs and route the wires through the frame opening.


After the Drywall is Installed



Step Five: Cut the drywall.




Step Six:
Connect the speaker wires to
the baffle assembly and install
baffle assembly in frame. Do
not overtighten the baffle
screws.




Step Seven: Replace the metal grille.


FM8SUB




Step One: Remove the grille from the subwoofer frame.




Step Two:Determine the correct subwoofer location.




Step ThreeCut the drywall.




Step Four:Loosen the eight phillips head screws until the locking tabs turn inward.




Step FiveConnect the speaker wires to the baffle assembly.



Step Six: Place the subwoofer in the wall.




Step Seven:
Screw down each of the eight phillips head screws. The tabs will swivel into place and secure the unit to the rear surface of the drywall.




Step EightReplace the metal grille.


FM65CX




Step One: Remove the grille from the speaker frame.




Step Two:Determine the correct speaker location in the ceiling.




Step Three: Cut the drywall.




Step Four: Remove 4 phillips head screws that attach speaker to frame.




Step Five: Loosen the three phillips head screws on the frame, until the locking tabs turn inward.




Step Six: Place the frame assembly in the wall.




Step Seven:
Screw down each of the three phillips head screws. The tabs will swivel into place and secure the unit to the rear surface of the drywall.



Step Eight:Connect the speaker wires to the speaker.



Step Nine:Reinstall speaker in frame, using 4 phillips head screws.



Step Ten:Replace the metal grille.

Painting the Speaker Frame and Grille

FM Series loudspeakers can be painted to match any style of decor. If you wish to change their color, the satin finish on the grille and frame will function as a primer coat. Before painting install the paint guard (in the assembly kit) securely into the recess in the baffle.

This will protect the speaker components and baffle from paint residue.

Use a high-quality spray paint, and apply a thin coat of color. Be certain the grille perforations remain free of paint. Filling them with paint will diminish the sound quality.

Note: Gently remove the acoustical blanket from the back of the grille before painting. Reattach the acoustical blanket after the paint has dried.

Troubleshooting

If there is no sound from either of the speakers, check the following:

- Receiver/amplifier is on and a source is playing.
- Check all wires and connections between receiver/amplifier, in-wall room volume control and speakers. Make sure all wires are connected. Make sure none of the speaker wires are frayed, cut, or punctured.
- Review proper operation of your receiver/amplifier.

If there is no sound coming from one speaker, check the following:

- Check the "Balance" control on your receiver/amplifier.
- Check all wires and connections between receiver/amplifier, and speakers. Make sure all wires are connected. Make sure none of the speaker wires are frayed, cut, or punctured.

If there is low bass output, check the following:

• Make sure the connections to the left and right "Speaker Inputs" have the correct polarity (+ and -).

If the system plays at low volumes but shuts off as volume is increased, check the following:

- Check all wires and connections between receiver/amplifier and speakers. Make sure all wires are connected. Make sure none of the speaker wires are frayed, cut, or punctured.
- If more than one pair of main speakers is being used, check the minimum impedance requirements of your receiver/amplifier.

Specifications

FM52 FM62 SYSTEM Frequency Response (-6dB): 50Hz - 20kHz 40Hz - 20kHz Recommended Maximum Amplifier Power*: 40 watts 50 watts Sensitivity: 88dB 90dB Impedance: 8 ohms nominal 8 ohms nominal Crossover Frequency: 6kHz 5kHz Woofer: 5-1/4" 6-1/2"

 Wooter:
 5-1/4"
 6-1/2"

 Tweeter:
 1" titanium
 1" titanium

 Outside Dimensions (HxW):
 11 x 7-1/2 inches
 13 x 7-1/2 inches

 280 x 190mm
 330 x 190mm

FM65C

50 watts

90dB

7kHz

6-1/2"

1" titanium

206mm (dia.)

45Hz - 20kHz

8 ohms nominal

8-1/8 inches (dia.)

SYSTEM FM82 FM8SUB
Frequency Response (-6dB): 35Hz - 20kHz 32Hz - 300Hz
Recommended Maximum
Amplifier Power*: 60 watts 120 watts

 Sensitivity:
 88dB
 88dB

 Impedance:
 8 ohms
 8 ohms

 Crossover Frequency:
 5kHz
 300Hz

 Woofer:
 8"
 8"

 Tweeter:
 1" titanium
 N/A

Outside Dimensions (HxW): 15-1/8 x 11 inches 11-13/16 x 11-13/16 inches 385 x 280mm 300 x 300mm

Occasional refinements may be made to existing products without notice, but will always meet or exceed original specifications unless otherwise stated.

*The maximum recommended amplifier power rating will ensure proper system headroom to allow for occasional peaks. We do not recommend sustained operation at these maximum power levels.



JBL Incorporated 8500 Balboa Boulevard, Northridge, CA 91329 1-800-336-4JBL (4525) (USA only)

© 1996 JBL, Incorporated.

JBL is a registered trademark of JBL, Incorporated.

Printed in USA 7/96 Part No. FMOM

harman consumer group harman consumer group

Declaration of Conformity



We, JBL Europe A/S Kongevejen 194B DK-3460 Birkerød DENMARK

declare in own responsibility, that the products described in this owner's manual are in compliance with technical standards:

EN 50 081-1/1992 EN 50 082-1/3.1995

> Steen Michaelsen JBL Europe A/S Birkerød. DENMARK. 7/96